Plantronics Explorer 10

User Guide

Contents


```
Welcome 3
What's in the Box
Headset Overview 5
Pair and Charge 6
  Get Paired 6
  Activate pair mode 6
  Use two phones 6
  Reconnect 6
  Charge 6
Fit 7
The Basics 8
  Answer or end a call 8
  Adjust the volume 8
  Mute 8
  Redial
         8
  Voice dial (phone feature) 8
  Toggle Voice Prompt On/Off 8
Specifications 9
```

Welcome

Congratulations on purchasing your new Plantronics product. This guide contains instructions for setting up and using your Explorer 10 headset.

Please refer to the safety instructions for important product safety information prior to installation or use of the product.

What's in the Box





NOTE Contents may vary by product.

Headset Overview



Charge port

Call button

Volume button: Cycle through volume settings

Headset LED (indicator light)

Power button

Pair and Charge

Get Paired

Be safe! Please read the separate safety guide for important safety information.

Wearing your headset, power it on. The first time you do this it will begin the pairing process. You hear "pairing" and the headset indicator lights flash red and blue.



- 2 Activate Bluetooth® on your phone and set it to search for new devices.
 - iPhone Settings > Bluetooth > On*
 - Android[™]Settings > Bluetooth: On > Scan for devices*

NOTE *Menus may vary by device.

3 Select "PLT E10."

If necessary, enter four zeros (0000) for the passcode or accept the connection.

Once successfully paired, you hear "pairing successful."

Activate pair mode

Press the Call button © until the indicator light flashes red and blue and you hear "pairing."

Use two phones

Multipoint technology lets you pair a second phone and answer calls on either phone. To pair a second or a new phone see "Activate pair mode."


Reconnect

Bluetooth headset has up to a 33 feet (10 meters) effective range. If you lose connection, your headset will try to reconnect. If your headset doesn't reconnect, tap the Call button © or manually connect through the phone's Bluetooth device menu.

Charge

Your new headset has enough power to pair and make a few calls. It takes 2 hours to fully charge the headset; the indicator light ight items off once charging is complete.

You can wear your headset on your right or left ear. To adjust the fit, rotate the earloop as shown.



The Basics



Answer or end a call Tap the Call button.

On/Off

Adjust the volume Tap the Volume button • to cycle through preset levels.

Mute While on an active call, press and hold the Volume button •) for 2 seconds. You hear "mute on" or

"mute off."

Redial To call your last number dialed, double tap the Call button ©.

Voice dial (phone feature) Press the Call button © for 2 seconds, wait for the phone prompt and then tell the phone to dial

the name of a stored contact.

Toggle Voice Prompt When the headset is powered on and you are not on a call the voice prompts can be turned off by

pushing the volume 🕪 button and the call ©button for more than 4 seconds.

Specifications

Talk Time	Up to 11 hours
Standby Time	Up to 12 days
Operating Distance (Range)	Up to 33 feet (10 meters), Class II
Headset Weight	11 grams
Charge Connector	Micro USB charging
Battery Type	Rechargeable non-replaceable lithium ion polymer
Charge Time (Maximum)	2 hours for full
Power Requirements	5V DC – 180mA
Bluetooth Version	Bluetooth v3.0
Bluetooth Profiles	Hands-Free (HFP) Profile 1.6 and Headset (HSP) Profile 1.2; Advanced Audio Distribution Profile (A2DP)
Operating Temperature	32°F - 122°F (0 - 50°C)
Storage Temperature	-40°F - 185°F (-40 - 85°C)
Charging Temperature	32°F - 104°F (0 - 40°C)

Support

EN	FI	NO
Tel: 0800 410014	Tel: 0800 117095	Tel: 80011336
AR	FR	PL
Tel: +44 (0)1793 842443*	Tel: 0800 945770	Tel: +44 (0)1793 842443*
CS	GA	РТ
Tel: +44 (0)1793 842443*	Tel: 1800 551 896	Tel: 0800 84 45 17
DA	HE	RO
Tel: 80 88 46 10	Tel: +44 (0)1793 842443*	Tel: +44 (0)1793 842443*
DE	HU	RU
Deutschland 0800 9323 400	Tel: +44 (0)1793 842443*	Tel: 8-800-100-64-14
Österreich 0800 242 500 Schweiz 0800 932 340		Tel: +44 (0)1793 842443*
EL	IT	SV
Tel: +44 (0)1793 842443*	Tel: 800 950934	Tel: 0200 21 46 81
ES	NL	TR
Tel: 900 803 666	NL 0800 7526876	Tel: +44 (0)1793 842443*
	BE 0800 39202	
	LUX 800 24870	

^{*}Support in English

Safety information: see the separate "For Your Safety" booklet 2-year limited warranty details: plantronics.com/warranty

NEED MORE HELP?

plantronics.com/support

plantronics® Simply Smarter Communications™

Plantronics BV Plantronics, Inc. 345 Encinal Street South Point Building C Santa Cruz, CA 95060 Scorpius 140

United States 2132 LR Hoofddorp, Netherlands

© 2015 Plantronics, Inc. Plantronics, Plantronics, Plantronics Explorer and Simply Smarter Communications are trademarks of Plantronics, Inc. registered in the US and other countries, and Explorer is a trademark of Plantronics, Inc. Bluetooth trademarks are owned by Bluetooth SIG Inc., any use by Plantronics, Inc. is under license. iPhone is a trademark of Apple Inc., registered in the US and other countries. All other trademarks are the property of their respective owners.

Patents pending 203760-06 (06.15)